




# CREATOR

5865






1




2


2




3




4




5



6




7









8




9







10




11



12




1




2



3




4







13




14



15






1




2




3




4




5




6




7



8




9







10




11




1




2




12




13




14




15







1




2




3




4



5




6







7



8




1




2




3




9




10



11



12





2x  
4558952



2x  
242001



1x  
4289272



1x  
379501



2x  
460026



1x  
4124096



3x  
241226



4x  
4508215



1x  
4107736



1x  
4106356



3x  
302328



2x  
4272665



3x  
371028



2x  
302028



2x  
4107637



1x  
4522673



2x  
4210828



2x  
4167842



2x  
4244362



2x  
4260942



4x  
4222960




1x  
4211469



4x  
4211525



2x  
4215513



1x  
4211406



2x  
4225532



1x  
4211356



2x  
4211399



4x  
4211765



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

[www.lego.com/service](http://www.lego.com/service) or dial




: 00800 5346 5555

: 1-800-422-5346





# CREATOR



©2009 The LEGO Group. 4582774

