




CITY

7499



7499

+




60052



7499

+



60050

+



60051

+



60052




7499

+



60051



Train trouble-shooting guide
 Anleitung zur Fehlerbehebung bei Zügen
 Guide de dépannage du train
 Guía de solución de problemas ferroviarios
 Guia de resolução de problemas do comboio
 Vasúti javítási útmutató
 列车故障指南

LEGO.com/city

