



CITY

60090



 [LEGO.com/city](https://www.lego.com/city)

1



2



3



2

1



1




2






1x

1



1x


2






2x

3




6



1x

4




1x



1x

5






1x



1x


6






1x

7



1x


8





1x

9







1x




2x

10





11




12



2x

12





2x




2x

13


1



2



2x





2x



2x

14


1



2



2x




15




1x

15



16





CITY



60090



60091



60092



60093



60095

LEGO.COM/CITY



1x
4140562



1x
6100222



2x
4289538



2x
4211398



2x
6012812



1x
4500608



1x
4298617



1x
302026



1x
6059027



1x
6028812



1x
4211043



1x
4210812



2x
6107179



1x
6107232



1x
4167842



2x
4565433



2x
6071226



2x
6107171



1x
6079001



1x
6107228



1x
4499885



1x
4258308



2x
4119482



1x
4161331



2x
6043130



2x
4143005



2x
3005749



1x
4160868



2x
604126



1x
6107178



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555



: 1-800-422-5346