





# Mixels







1





2







3





4






5




6






2x


7





2x

8







9




10







11





12






13



14









2x


# 15





1x

# 16






17




18






1x

# 19



1x



# 20






2x


# 21





1x

# 22









23




24







**1**





**2**







3




4






5





6






# 25




# 1







2




3







4




5







6






26







# 27





# 28



LEGO, the LEGO logo and MIXELS are trademarks and/or copyrights of the/sont des marques de commerce et/ou copyrights du/son marcas registradas, algunas de ellas protegidas por derechos de autor, de LEGO Group. ©2014 The LEGO Group. All rights reserved/Tous droits réservés/Todos los derechos reservados.

TM & © 2014 Cartoon Network.

Customer Service  
Kundenservice  
Service Consommateurs  
Servicio Al Consumidor  
LEGO.com/service or dial

								: 00800 5346 5555	
								: 1-800-422-5346	