



CREATOR


31058



LEGO.com/creator



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.

Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA: PELIGRO DE ASFIXIA.

Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.




1x



1x

1



2





1x





2x

2






3





1x

4




4



1x

5






1x




1x


6




1x

7







8



6




9





1x

10





2x




1x

11








12






13





14


1




2




3





4




5







6









15



5



6





2x



2x



2x



4x



2x




4x




2x

16


1



2




3





4




5





2x








17








18







19







20





21






22




23





1x

24






1x



1x


25






1x


26



1x


27






1x

28



1x

29



30

