




CREATOR


31079




[LEGO.com/creator](https://www.lego.com/creator)


3 in 1
3 en 1
3 em 1
3 az egyben
3 合 1






1






2





2x

3







4




4x





5





1x





2x




1x

6





7






1x




1x


8






9





10





2x




2x



1x

11






1x



2x

12






2x



2x

13





2x




2x



2x

14






1x



2x

15





1x




1x



2x

16






1x



2x

17






2x



2x

18






2x



2x


19





2x


20





1x

21





1x





1x




2x

22






23





2x

24






2x



2x


25





2x

26







2x




2x

27





28






3x





2x

29






3x






30





31






1x




2x

32





33





2x



2x




2x



1x

34






2x



2x

35








2x





2x

36






37






38







39








40








41







42



43







2x
366624




5x
300924



2x
379524



1x
4189400



2x
303424




3x
6079138



1x
306826



1x
383926



2x
370326



1x
73587



1x
6015891



4x
614126



3x
6139403



2x
4223247



1x
6132731



4x
4541455



3x
241226



1x
4521681



1x
6047056



1x
4168345



2x
4597999



1x
6146503



8x
4638658



2x
4167504



1x
4173328



1x
4162916



4x
4528981



2x
4205004



2x
6168645



2x
4646865



2x
4542673




2x
4280341



2x
421288



1x
4211190



1x
4211204



2x
6152107



2x
6151688



3x
6176433



4x
6071229



3x
4211415



1x
4211475



4x
4211807



4x
6144138



6x
4211350



4x
4211519



2x
4211414



3x
4598526



4x
6117967



4x
6044729



4x
4244627



3x
4535738



3x
6126082



1x
6177078



2x
4515369



2x
4211429



1x
4558169




4x
4211356



1x
4599498



2x
6081975



2x
4211549



1x
4211452



2x
4211407



1x
4211051



1x
6092572



4x
6000606



2x
4210660



2x
4210718



1x
6206151



1x
4549990



1x
6173694



2x
6030333



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



CREATOR

31076

3^{IN}1



LEGO and the LEGO logo are trademarks
of the LEGO Group. ©2018 The LEGO Group. 6226453