



Disney

40307



1



2



3



4





1



2



1



2



1



2



1



2



1



2



1



2




1




2




1




2




1




2



1




2



1




2






1







2




3









1



2



3




4






1



2




3




4







1




2




3




4




5




6




7




8




9




10




11




12




13




14




1



2



3




4



5




6



7







1



2



3




4







1




2





3







4








6








5



6



A




B



40388



41154



41152



- | | | | | | | | | | |
|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| 1x
6173141 | 2x
6034044 | 2x
4567449 | 1x
245401 | 4x
4625616 | 1x
6136419 | 3x
4667331 | 1x
4243920 | 1x
6100565 | 1x
4567332 |
| 2x
307001 | 3x
300401 | 2x
366501 | 1x
285401 | 2x
6138507 | 1x
6133667 | 1x
6060795 | 1x
4538126 | 1x
3006840 | 1x
4114505 |
| 2x
403201 | 2x
403201 | 1x
6117940 | 2x
302001 | 2x
6062386 | 1x
6060795 | 1x
6134672 | 2x
6050916 | 3x
6112751 | 1x
6058337 |
| 1x
4119410 | 1x
4113261 | 1x
6117940 | 2x
302001 | 2x
6062386 | 1x
6096589 | 1x
6134673 | 7x
4523159 | 1x
4119482 | 1x
6097448 |
| 4x
302301 | 2x
6055541 | 1x
4530590 | 1x
6109930 | 2x
4619517 | 4x
4550359 | 2x
6035291 | 6x
6083975 | 1x
6052994 | 2x
4143404 |
| | | | 2x
6037658 | 2x
4619521 | 2x
4620318 | 1x
6157942 | 2x
6143597 | 1x
4273743 | 1x
6023826 |
| | | | | 2x
4653970 | 2x
6097501 | 1x
6135278 | 1x
6173109 | | |
| | | | | | 2x
6097098 | 1x
6097098 | 2x
6112307 | 1x
6218085 | |
| | | | | | 2x
6030277 | 3x
6212994 | 4x
6092594 | 1x
6218642 | |



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :

