





Disney


41162



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.








AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.
No recomendado para niños menores de 3 años. Contiene piezas pequeñas.






1





2x

2







1x



2x


3





1x


4





2x


5






2x


6





7






8


1




2




3







9







2x




1x

10






11







2x

12






13







2x

14





15






1x



1x

16







1x




2x


17






1x






1x




1x

19



2x


20





1x

21




1x





1x

22






23






2x



1x

24






1x




1x

25



1x


26





4x

27



28




1x




1x

28



29








1x



1x




30





2x

31







2x



2x

32






1x



2x


33





2x



34






2x

35





1x

36







37






38





2x

39




38



2x

40




2x



2x


41





1x

42




40




1x

43



1x


44





2x

45





42



2x


46





1x

47




2x



2x


48





1x

49





44





2x

50






51




52







53



54






1x

55

1




2






56

1






2



3









57


1



2



3





58



52





1x
434601



3x
614301



4x
6093053



2x
6092873



1x
6051511



1x
393701



2x
6261349



4x
6137926



6x
6070698

54



1x
6097637



6x
4535737



1x
6013866



1x
6001512



1x
6238334



1x
4494474



1x
242001



1x
6245249



4x
6249091



2x
6034675



1x
4541956



3x
6097097



1x
302001



1x
663601



3x
6247796



6x
6053876



6x
6240228



1x
6249033



2x
6195358



4x
6099349



1x
6209806



1x
6099361



3x
6247796



6x
6053876



6x
6240228



1x
6249033



4x
6250124



1x
6087084



2x
6039479



1x
6252410



1x
4273743



2x
6166107



3x
6167812



1x
6253230



1x
6246890



2x
6210440



1x
6099370



2x
6060795



1x
6096990



5x
4286050



7x
4517993



4x
6204509



2x
6253011




2x
6175307



2x
4520632



2x
6249953



1x
6253341




1x
6034425



1x
6252351



1x
452926



1x
6023827



1x
6133790



1x
6252352



1x
6252355



1x
6240209



1x
6240231



1x
6191627



1x
6251843



1x
6171101



2x
6182261



1x
6254070



1x
4119479



1x
6210746



2x
4594238



3x
6043656



1x
6126082



1x
4211881



1x
4211881



1x
4211491



1x
6063611



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial




: 00800 5346 5555

: 1-800-422-5346

1



2



3

