



# Disney

43278



**WARNING:**  
**CHOKING HAZARD.**  
Toy contains small parts and  
a small ball.  
Not for children under 3 years.

3



## AVERTISSEMENT :


**RISQUE D'ÉTOUFFEMENT.** Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.



## ADVERTENCIA:


### PELIGRO DE ASFIXIA.


Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.







1







2







3







4






5








6






7






8






9






10







11





12






13







14






15





16


1




2




3









17







18







19







20







21





22





23

1



2



3




4




5








24







25






26







27









29







30










32






33






34







35






36






37








39






40





41





42

